

Document title OVERVIEW for service sheet

Document number ap0020p1228gy

Model 463.206/240/243/246/247/249/254/270/271
Model 463.209/232/233/244/245/250
Model 463.222
Model 463.241/248
 Except special protection version
Model 463.303/340/341/343
Model 463.308/330/331
Model 463.309/332/333
Model 463.322/323

- ☐
☐
☐
☐
☐
☐
☐
☐
☐
☐
☐
☐

Service A

Service B

Every year

Every 3 years

Every 5 years

Once at 60,000 km (37,500 mi)

Every 50,000 km (31,000 mi)/2 years

Every 80,000 km (50,000 mi)/4 years

Every 90,000 km (56,000 mi)

Every 120,000 km (74,500 mi)/4 years

Every 250,000 km (155,000 mi)/15 years



P00.00-4922-11

Customer	Order number
VIN/license plate number	Current mileage
Service code	Workshop code
Remaining distance	Remaining time
Oil type/viscosity	Completion time/date
Service consultation performed at vehicle	Yes No
Notes/explanations	

The following activities are hereby confirmed:

- Completion of relevant service operations

Signature

A	B		Input condition not OK:
Completed			☒
☒	☒		
↓	↓		↓
☐	☐	Service reception The reception report for service on the vehicle is available in completed form.	☐

AP00.20-P-0009Z

		i To be performed by the Service Advisor (where market-specific conditions require). Fully process all acceptance items and the maintenance items listed in the service sheet, only then is the service scope completely performed.	
☐	☐	Brake system Perform brake test and enter result in table. Up to model year 2019	○ AP42.00-P-4290G
☐	☐	Vehicle exterior Check exterior lighting for proper operation.	○ AP82.10-P-8252EW
	☐	Check function of headlamp range adjustment. Vehicles with Xenon headlamps or headlamp range controller on exterior lights switch	○ AP82.10-P-8250EW
	☐	Check and correct headlamp adjustment. Up to model year 2019 i For vehicles with xenon headlamps, the adjustment of the headlamps is to be invoiced as an additional operation.	○ AP82.10-P-8260G
☐	☐	Vehicle interior Check windshield wipers, windshield washer system and headlamp cleaning system for proper operation. Up to model year 2019	○ AP82.30-P-8252G
☐	☐	Check lamps in instrument cluster and interior lighting for proper operation.	○
☐	☐	Check first-aid kit (soft sided). i Enter first aid bag expiration date here: i Replace first aid bag, invoice as an additional operation.	○ AP68.00-P-6850EW
☐	☐	Check seat belts and seat belt buckles for external damage and proper operation. Up to model year 2019	○ AP91.40-P-9150GI
	☐	Soft top hydraulics: Check oil level. Convertible with hydr. soft top	○ AP77.37-P-7710G
	☐	Soft top: Check lock element. Convertible with hydr. soft top	○ AP77.33-P-7750G
☐	☐	Trunk Check trunk lighting for proper operation.	○
	☐	Body Lubricate door locks. Up to model year 2019	AP72.00-P-7221G
☐	☐	Engine compartment Hood: Check latch and safety hook for ease of movement. Up to model year 2019	○ AP88.40-P-8821G
☐	☐	Brake system: Check fluid level. Up to model year 2019	○ AP42.10-P-4210C
☐	☐	Differential lock operating system: Check fluid level. Up to model year 2019	○ AP29.00-P-2913A
☐	☐	Windshield washer system: Check/correct fluid level. Up to model year 2019	AP82.35-P-8210G

			i When using cleaning compounds for summer/winter, and depending on the ambient temperature, observe the mixing ratio.		
	☐	☐	Power steering system: Check fluid level.	 ○	
			Up to model year 2019		AP46.00-P-4612B
☐	☐	☐	Battery: Check/correct fluid level.	 ○	
			Except low-maintenance battery Up to model year 2019		AP54.10-P-5410G
☐	☐	☐	Engine cooling system: Check coolant level and antifreeze content.	 ○	
			Engine 112, 113 Engine 273, 642 Engine 606, 612, 628		AP20.00-P-2010GA AP20.00-P-2010GY AP20.00-P-2010G
			i Enter antifreeze content here: _____ °C		
	☐	☐	Engine control system: Check and lubricate ball joints.	 ○	
			Except engine 273, 642		AP30.10-P-3022G
☐	☐	☐	Check all visible parts in upper area of engine compartment for damage and leaks.	 ○	
			Up to model year 2019		AP00.20-P-0055F
	☐	☐	Check all visible parts in engine compartment for damage and leaks.	 ○	
			Up to model year 2019		AP00.20-P-0055F
	☐	☐	Replace activated charcoal filter.		
			as of model year 2000		AP83.00-P-8381GA
☐	☐	☐	Engine: Change oil and oil filter.		
			Engine 112, 113.962 Engine 113.982 Engine 113.993 Engine 273 Engine 606 Engine 612 ENGINE 628 Engine 642		AP18.00-P-0101GB AP18.00-P-0101GBA AP18.00-P-0101GBB AP18.00-P-0101GG AP18.00-P-0101A AP18.00-P-0101GDA AP18.00-P-0101GDB AP18.00-P-0101GY
	☐	☐	Air conditioning system: Check refrigerant level.	 ○	
			Vehicles with air conditioning Up to model year 2019		AP83.30-P-8312G
	☐	☐	Check poly-V-belt in visible area for signs of wear.	 ○	
			Engine 112, 113 Engine 273, 242 Engine 606 Engine 612, 628		AP13.22-P-1351GA AP13.22-P-1352GY AP13.22-P-1351A AP13.22-P-1351GD
	☐	☐	Underside of vehicle Check all visible parts of vehicle underside for damage and leaks.	 ○	
			Up to model year 2019		AP00.20-P-0054H
	☐	☐	i The country-specific regulations for mobility and body shell complaints apply.	 ○	
			Up to model year 2019		AP46.00-P-4651F
	☐	☐	Steering: Retighten bolts.		
			Up to model year 2019		AP46.20-P-4671G
	☐	☐	Check condition of front axle and front axle joints.	 ○	
			Up to model year 2019		AP33.10-P-3358F
	☐	☐	Front axle: Check/correct grease quantity in joint housing.	 ○	
			Up to model year 2019		AP33.10-P-3321G
	☐	☐	Transfer case: Check oil level.	 ○	
			Transfer case 750.65		AP28.00-P-2810G
☐	☐	☐	Fuel system: Drain water separator.		

	☐	Check condition of propeller shafts.	With CODE KL5 (Fuel filter with water separator)	○	AP47.20-P-0794GL
	☐	Check condition of rear axle and rear axle ball joints.	Up to model year 2019	○	AP41.10-P-4154A
	☐	Check condition of suspension struts or shock absorbers and springs.	Up to model year 2019	○	AP35.20-P-3552F
☐	☐	Check tires for damage and crack formation, and enter result in table.	Up to model year 2019	○	AP32.25-P-3255F
			Up to model year 2019		AP40.10-P-4051GM
☐	☐	Tires Correct tire pressure and enter set tire pressure in table.	 Up to model year 2019	○	AP40.15-P-4060G
☐	☐	Check/correct spare wheel tire pressure and enter set tire pressure in table.	 Vehicles with spare tire Up to model year 2019	○	AP40.15-P-4060G
☐	☐	Engine compartment Every year Brake system: Replace brake fluid.	 Up to model year 2019		AP42.00-P-4280D
☐	☐	Differential lock operating system: Replace brake fluid.	 Up to model year 2019		AP29.00-P-2982G
☐	☐	Underside of vehicle Every 3 years Replace coolant in main circuit.	 Engine 606, 628		AP20.00-P-2080G
☐	☐	Vehicle interior Every 5 years Sliding roof: Clean and lubricate slide rails and slide shoes.	 Vehicles with sliding roof		AP77.20-P-7730G
☐	☐	Underside of vehicle Once at 60,000 km (37,500 mi) Automatic transmission: Change oil and oil filter.	 Transmission 722.6 Transmission 722.9		AP27.00-P-2702GW AP27.00-P-2702W
☐	☐	Engine compartment Every 50,000 km (31,000 mi)/2 years Replace air filter element.	 Engine 112, 113, 606 Engine 273 Engine 612 ENGINE 628 Engine 642		AP09.10-P-0980A AP09.10-P-0980GG AP09.10-P-0980GI AP09.10-P-0980C AP09.10-P-0980GZD
☐	☐	Underside of vehicle Every 80,000 km (50,000 mi)/4 years Replace fuel filter.	 Engine 112, 113, engine 273 up to model year 2013 Engine 273 as of model year 2013		AP47.20-P-0780GX AP47.20-P-0780AB
☐	☐	Fuel prefilter with water separator: Replace fuel filter element.	 With CODE KL5 (Fuel filter with water separator)		AP47.20-P-0783GL
☐	☐	Front axle differential: Change oil.	 Except model 463.270/271		AP33.00-P-3301G

☐	☐	Rear axle differential: Change oil.	----- Except model 463.270/271	AP35.00-P-3501G
☐	☐	Engine compartment Every 80,000 km (50,000 mi)/4 years Replace fuel filter.	----- Engine 606 Engine 612 ENGINE 628 Engine 642	AP47.20-P-0780BA AP47.20-P-0780BE AP47.20-P-0780BC AP47.20-P-0780EWO
☐	☐	Replace fuel prefilter.	----- Engine 606	AP47.20-P-0781AC
☐	☐	Replace spark plugs.	----- Engine 112, 113 Engine 273	AP15.10-P-1580GA AP15.10-P-1580GG
☐	☐	Underside of vehicle Every 90,000 km (56,000 mi) Front axle differential: Change oil.	----- Model 463.270/271 up to model year 2019	AP33.00-P-3301G
☐	☐	Rear axle differential: Change oil.	----- Model 463.270/271 up to model year 2019	AP35.00-P-3501G
☐	☐	Underside of vehicle Every 120,000 km (74,500 mi)/4 years Transfer case: Change oil.	----- Transfer case 750.65	AP28.00-P-2801G
☐	☐	Underside of vehicle Every 250,000 km (155,000 mi)/15 years Replace coolant in main circuit.	----- Engine 112, 113 Engine 273, 642 Engine 612	AP20.00-P-2080GA AP20.00-P-2082F AP20.00-P-2080G

Brake values

	Left	Right
Front		
Rear		
Parking brake		

Tire condition

	Right front	Left front	Right rear	Left rear
Condition OK.				
Condition not OK.				

Set tire pressure in bar or psi

	Front axle	Rear axle	Spare wheel
bar/psi			